

Available for Built to Order and QS Series




SAM Fan Filter Units and Light Fixtures are equipped with power cords for plugging into receptacles mounted on a top cross rail.

Receptacle(s) are connected to flexible conduit which connects to a field connection junction box.

A qualified electrician can then connect the host building power to the QS Softwall Cleanroom.

A control box mounted on a leg is equipped with switches for the SAM Units and Light Fixtures. The number of switches will be appropriate or in direct proportion to the number of SAM units and light fixtures.

Connecting to the building power source and compliance with state, city, county or township codes is the responsibility of the buyer.



Flexible Solutions Softwall Cleanrooms are considered a piece of equipment and are in compliance with accepted national practices for wiring of equipment.

Lead time for the electrical option requires an additional 5 business days. Consult with the factory for more information.

Available for Built to Order and QS Series

General Information

Adding a Caster Package permits the Softwall Cleanroom to be moved from one location to another.

All casters are polyurethane swivel type and are equipped with brakes (Fig. 2) to prevent movement when the cleanroom is in use.

To insure stability during a move, Caster Option 1 includes up to (8) Diagonal braces (Fig. 3). Cleanrooms with 1-4 sides consisting of all strips utilize two (2) Diagonal braces per side as shown on Fig. 1. Diagonal braces can also be used on sides with solid curtains.

Caster Option 2 includes three (3) Leg Stabilizers for sides with solid curtains as shown in Fig. 4.

Lead Time


Lead time for the electrical option requires an additional 5 business days. Consult with the factory for more information.

Ordering Information

- 805079.....Casters, 4" x 2" w/brake (4) req'd.
- 966002.....Diagonal Brace
- 966018.....8 Ft. Leg Stabilizer
- 966019.....10 Ft. Leg Stabilizer
- 966020.....12 Ft. Leg Stabilizer

Moving a portable Softwall Cleanroom may involve some risk and danger to the equipment or personnel. Observe all appropriate safety regulations when moving a Softwall Cleanroom equipped with casters.

DO NOT allow personnel to be inside the cleanroom during the moving process.



DO NOT attempt to move cleanroom across uneven or inclined surfaces.

When moving a portable cleanroom, **DO NOT** use a fork lift, portable hoist, pallet jack or other lifting devices. Use at least one person per leg when moving the cleanroom.





Fig. 1




Fig. 2

Caster Detail




Fig. 3

Diagonal Brace Detail




Fig. 4

Caster Option 2: Leg Stabilizers